


Thank you for purchasing a PSS faucet. By following the care instructions on this page you will enjoy this quality faucet for many years to come.

Care Instructions

To clean, wipe gently with a soft, damp cloth, then wipe dry. The faucet finish is very durable, however to ensure a long lasting luster, harsh abrasives or polishes should be avoided.

Parts List

- A - Main Body - Solid Brass
- B - Spout
- C - Infrared Sensor Eye
- D - Deck Cover Plate (Installation Optional)
- E - Enhanced Plastic Washer
- F - Stainless Steel Washer
- G - Basin Nut
- H - Waterproof Connect Cable
- I - Faucet Supply Hose
- J - Filter
- K - Control Module
- L - Battery Cover
- M - On/Off Button
- N - Mechanical Mixing Valve
- O - A/C Adapter (Not Included)
- P - Water Supplies (Not Included)



LAVATORY SENSOR FAUCET INSTALLATION INSTRUCTIONS

Faucet Operation

- 1 - Place hands under the spout (B). Water starts to flow. Water will continue to flow while hands remain under the spout (B)
- 2 - Clean the filter (J) once a month
- 3 - Keep Infrared Sensor Eye cover clean (C)
- 4 - Constant red light on the Sensor Eye (C) indicates weak power. Batteries need to be replaced
- 5 - If both AC Adapter (not included) and batteries are equipped. Batteries will only be used if power is lost to the AC Adapter
- 6 - Fresh Batteries will turn water on/off 400,000 times

Sensor Range Setup

- 1 - Press and hold the On/Off button (M) for 5-7 seconds until Red Light appears on the sensor eye (C). Then Release Button.
- 2 - Place Hands 5-7cm under the spout (B). Wait 5-10 seconds until Red Light on the sensor eye (C) begins to flash.
- 3 - Place one hand in the desired distance from spout and press the On/Off button (M) with your other hand
- 4 - Sensor Range Setup is now Complete

Battery Installation

- 1 - Four "AA" Alkaline Batteries are required
- 2 - Unscrew the three screws on the battery cover (L)
- 3 - Remove the Battery Cover and Old Batteries
- 4 - Hold On/Off button for 7-10 seconds to erase the CPU memory
- 5 - Install the four fresh "AA" Alkaline Batteries
- 6 - Red Light on Sensor Eye (C) will flash, this indicates normal function will return (if batteries had worn out)
- 7 - Screw the battery cover back on properly.



This product has been tested and is in compliance with the following standard:
 ASME A112.18.1 / CSA B125.1

LEAD FREE

This product is in compliance with low lead requirements to have no more than a weighted average lead content of 0.25% on wetted surfaces.


Merci pour l'achat d'un robinet PSS. Par suite de la soin et des instructions d'utilisation sur cette page vous pouvez apprécier ce robinet de qualité pour de nombreuses années à venir.

Instructions De Soins

Pour nettoyer, essuyer doucement avec un chiffon doux et humide, puis séchez. La finition du robinet est très durable, mais pour s'assurer à long éclat durable. abrasifs ou de cirages doivent être évités.

Liste Des Pièces

- A - Corps Principal - Laiton Massif
- B - Bec
- C - Oeil Capteur Infrarouge
- D - Couvercle de Ponte (Installation Optionelle)
- E - Rondelle De Plastique Supérieur
- F - Rondelle En Acier Inoxydable
- G - Écrou De Lavabo
- H - Câble De Connexion Étanche
- I - Tuyau D'alimentation Robinet
- J - Filtre
- K - Module De Contrôle
- L - Couvercle Des Piles
- M - Bouton Sur/Hors
- N - Vanne Mécanique De Répartition
- O - C. A. Facultatif (non inclus)
- P - Connecteur D'Approvisionnement D'eau(Non Inclus)



ROBINET CAPTEUR LAVABO LES INSTRUCTIONS D'INSTALLATION

Opération Robinet

- 1 - Placez vos mains sous bec (B). L'eau commence à couler. L'eau continue de couler pendant que votre mains restent sous le bec verseur (B).
- 2 - Nettoyer le filtre (J) une fois par mois.
- 3 - Gardez la couverture Oeil Capteur Infrarouge (C) propre
- 4 - Constante lumière rouge sur le Oeil Capteur (C) indique la puissance faible. Piles doivent être remplacées.
- 5 - Si C. A. Facultatif (non inclus) et les piles sont équipés. Piles ne sera utilisé que si la puissance est perdue a la C.A. Facultatif.
- 6 - Nouvelles batteries se tourneront eau sur/hors 400,000 fois.

Configuration Oiel De Capteur

- 1 - Appuyez et maintenez le bouton (M) Sur / Hors (C) pour 5-7 secondes jusqu'à ce que voyant rouge s'allume sur le capteur de oeil (C). Relâchez le bouton.
- 2 - Placez les mains 5-7cm sous le bec (B). Attendre 5-10 secondes jusqu'à ce lumière rouge sur l'oeil du capteur (C) commence à clignoter.
- 3 - Placez une main dans le distance désirée de bec et appuyez sur le bouton Sur / Hors (M) avec votre d'autre part.
- 4 - Configuration plage du capteur est maintenant complète.

Installation Eatterie

- 1 - Quatre "AA" piles alcalines sont nécessaires (L)
- 2 - Dévissez les trois vis sur le couvercle des piles
- 3 - Retirez le couvercle des piles et batteries usagées
- 4 - Tenez bouton Sur / Hors pour les 7-10 secondes pour effacer le mémoire de la CPU
- 5 - Installer les quatre nouvelles piles "AA" alcalines
- 6 - Rouge lumière sur Oiel de capteur (C) se met à clignoter, cela indique fonction normale sera de retour (si les batteries étaient usés)
- 7 - Vissez le couvercle de la batterie sur le bien.